About FabricPool Licenses

Fujitsu would like to thank you for purchasing FabricPool.

The following operations are required prior to the use of FabricPool.

- Ordering a license
- · Registering a license

Ordering a License

Order a license to enable FabricPool.

To order a license, the following items are required for each license. Order these licenses after a system configuration is completed.


- When ordering an initial installation license
 The Cluster UUID and System Serial Number of the storage system that uses FabricPool
- · When ordering a capacity expansion license and period extension license
 - The Cluster UUID and System Serial Number of the storage system that uses FabricPool
 - The serial number of FabricPool

Registering a License

Register the license via ONTAP System Manager.

Procedure ▶▶ ■


- 1 Log in to ONTAP System Manager and select the "Configuration" tab.
- 2 Navigate to the "Licenses" page under "CLUSTER".
- 3 Click "+Add" from the menu.






4 Select the downloaded license file and click "Add".

ONTAP 9.8



ONTAP 9.9.1 or later



-	

Fujitsu Storage ETERNUS AX series All-Flash Arrays, ETERNUS AC series All-Flash Arrays, ETERNUS HX series Hybrid Arrays About FabricPool Licenses

P3AG-4762-04ENZ0

Date of issuance: April 2024 Issuance responsibility: Fujitsu Limited

- The content of this manual is subject to change without notice.
- This manual was prepared with the utmost attention to detail.
 However, Fujitsu shall assume no responsibility for any operational problems as the result of errors, omissions, or the use of information in this manual.
- Fujitsu assumes no liability for damages to third party copyrights or other rights arising from the use of any information in this manual.
- The content of this manual may not be reproduced or distributed in part or in its entirety without prior permission from Fujitsu.