Fsas Technologies Inc.

ETERNUS AX series All-Flash Arrays, ETERNUS AC series All-Flash Arrays, ETERNUS HX series Hybrid Arrays

# About ONTAP S3 Licenses

ONTAP S3 is incorporated in ONTAP 9.8 and later. The following operations are required prior to the use of ONTAP S3.

Obtaining a license

Registering a license

## **Obtaining a License**

To obtain the license key used to activate ONTAP S3, send an email including the serial number of the storage system to the following email address:

fj-et-fabricpool@dl.jp.fujitsu.com

### **Registering a License**

Register the license via ONTAP System Manager.

- 1 Log in to ONTAP System Manager and select the "Configuration" tab.
- 2 Navigate to the "Licenses" page under "CLUSTER".
- 3 Click "+Add" from the menu.

= nĝnu	ONT	AP System M	anager	Search actions, objects, and pages	٩		(	<b>)</b> ()	, <b>.</b>	
DASHBOARD		Licenses	Cluster Settings							
INSIGHTS		Featur	res Installed Licenses							
STORAGE			-							
NETWORK		+ Add			C.	Search Show /	Hide 🗸	<b>₹</b> Filter		
EVENTS & JOBS			Name	State 🚺						
PROTECTION		~	SMB/CIFS License	Compliant						
HOSTS		~	FC License	Compliant						
CLUSTER		~	FlexClone License	Compliant						
Overview		~	ISCSI License	Compliant						
Hardware		~	NFS License	Compliant						
Settings Disks		~	NVMe License	Compliant						
		~	53 License	Compliant						
		~	SnapLock License	Compliant						
		~	SnapManagerSuite License	Compliant						
		~	SnapMirror License	Compliant						
		~	SnapMirror Synchronous License	Compliant						

#### 4 Enter the downloaded license key and click "Add".

For ONTAP 9.9.1 or later, (1) select the "Use 28-character legacy keys" checkbox and then (2) enter the license key.

Add License	Add License	×
Adds one or more licenses to your application. You can either specify the license keys or select license files, or both.	Select one or more license files.	Browse
UCDNIE NTYL	Use 28-character legacy keys	(1)
Enter ficence keys tepwated by comman.		-
	Cancel	Add
UC3568-4U23		
Browse		
Literna Nes are required for features that use capacity-based learne		
	· · · · · · · · · · · · · · · · · · ·	
Cancel	Add License	×
Cancel		×
Cancel	LICENSE FILES	Browse
Cancel	UCENSE FILES Select one or more license files.	Browse
Cancel	LICENSE FILES	
Cancel	UCENSE FILES Select one or more license files.	Browse
Cancel	LICENSE FILES Select one or more license files.	Browse
Cancel	UCENSE FILES Select one or more "license files. Use 28-character legacy keys LEGACY KEYS	Browse
Cancel	UCENSE FILES Select one or more "license files. Use 28-character legacy keys LEGACY KEYS	Browse

**ONTAP 9.7 / ONTAP 9.8** 

#### ONTAP 9.9.1 or later

ETERNUS AX series All-Flash Arrays, ETERNUS AC series All-Flash Arrays, ETERNUS HX series Hybrid Arrays About ONTAP S3 Licenses

P3AG-6022-04ENZ0

Date of issuance: June 2025 Issuance responsibility: Fsas Technologies Inc.

- The content of this manual is subject to change without notice. •
- This manual was prepared with the utmost attention to detail. However, Fsas Technologies shall assume no responsibility for any operational problems as the result of errors, omissions, or
- Fast Technologies assumes no liability for damages to third party copyrights or other rights arising from the use of any information in this manual. •
- The content of this manual may not be reproduced or distributed in part or in its entirety without prior permission from Fsas Technologies.

Copyright 2020-2025 Fsas Technologies Inc.