

Data Sheet

Fujitsu PRIMERGY ServerView Suite ServerView® integrated Remote Management Controller - iRMC S2

Extensive remote control with the integrated Remote Management Controller

The ServerView integrated Remote Management Controller iRMC S2 enables extensive control of PRIMERGY servers regardless of their system status – even in out-of-band operation. It integrates remote management functionality with the basic system management functions on a chip on the motherboard.

The iRMC S2 is an autonomous system on the motherboard of a PRIMERGY system. It has its own operating system, web server, user administration and alarm management and it is also supplied with power when the server is in standby mode. Communication is carried out via a LAN connection, which can be shared with the PRIMERGY system or used exclusively for system management. The iRMC S2 forwards the signals from the keyboard, monitor and mouse digitally over the network. Apart from all free standard functions, an iRMC S2 advanced pack can be purchased enabling graphical console redirection - Advanced Video Redirection (AVR) - and the use of remote storage via USB.

The iRMC S2 gives administrators or service technicians access to the server for extensive control, even at decentralized locations. In the event of server problems, routine tasks and maintenance can be carried out efficiently.

The iRMC S2 is based on its successful predecessor iRMC and provides enhanced functionality. With iRMC S2 the overall system performance can be monitored. Thereby operating system independent control of power consumption is possible. By means of the Customer Self Service (CSS) concept for certain server components customers can do service on their own.



ServerView

Resourceful Server Management

PRIMERGY ServerView Suite provides all the necessary elements for professionally managing server systems across their lifecycle. For further information please visit www.ts.fujitsu.com/serverview



Features and Benefits

Main features	Benefits
<ul style="list-style-type: none">■ Universal solution for all PRIMERGY servers■ Full remote control and analysis of PRIMERGY servers■ Monitoring and control of power consumption■ Support of local service panel■ Customer Self Service (CSS) concept■ Efficient graphical console redirection (AVR)■ Remote Storage for up to two media	<ul style="list-style-type: none">■ No limitation of iRMC S2 functions depending on the server model■ Around-the-clock control, independent of the server status■ Specify the mode to control power consumption as required■ Determine which system component is faulty and whether you can replace the faulty component yourself■ Avoid time-consuming and cost-intensive call-outs■ No need for expensive external KVM switches■ Provides a "virtual" drive located elsewhere in the network

iRMC S2 - Hardware for Remote Management

Remote configuration and maintenance minimize time-consuming and cost-intensive call-outs.

The iRMC S2 permits system control, diagnosis, configuration and server restarting by remote access via the integrated web interface – even if the operating system or hardware fails. Errors can be analyzed and often also rectified right away. The system administrator is notified by email or SMS. The iRMC S2 offers access to remote storage resources (floppy disk, memory stick, CD/DVD, ISO image) via USB. Genuine headless system operation without a local mouse and keyboard is supported.

The iRMC S2 communicates directly via I²C with the hardware sensors, such as fans, and not only performs remote management tasks, but also the functions of a Baseboard Management Controller (BMC). It is thus able to take over functions such as power management or reading the System Error and Event Log (SEL) regardless of the system status.

The iRMC S2 offers enhanced security functions, including 128-bit SSL encryption and efficient user authentication to ensure maximum security.



integrated Remote Management Controller - iRMC S2

iRMC S2 – Technical data

VGA	Up to 1600 x 1200 and 16-bit colors or 1280 x 1024 and 24-bit colors or 1024x768 and 32-bit colors 32 MB attached memory
USB	USB 1.1/USB 2.0
IPMI	IPMI 2.0
DCMI	DCMI 1.0
Network	Shared / dedicated 10/100 MBit IPv4 and IPv6 support

iRMC S2 – System requirements

Managed Server	
Software	Windows Server 2003 Web Edition (32 bit) Windows Server 2003 R2 / Standard / Enterprise (32 bit / x64) Windows Server 2008 all editions (32/64 bit) Windows Server 2008 R2 all editions (32/64 bit) Windows EBS/SBS 2008 Red Hat Enterprise Linux 5 (x86 / EM64T) SuSE Linux Enterprise Server 10 (x86 / EM64T) Debian Fujitsu Server Edition (debian4you by Bytec) Note: not all operating systems have been released for all the hardware
Hardware	BX620 S5/S6, BX920 S1/S2, BX922 S2, BX924 S2, BX960 S1, CX122 S1, RX100 S5/S6, RX200 S4/S5/S6, RX300 S4/S5/S6, RX600 S4/S5, RX900 S1, TX120 S2, TX150 S6/S7, TX200 S4/S5/S6, TX300 S4/S5/S6
Administrator system	
Software	Microsoft Internet Explorer Version from Version 8.x Mozilla Firefox from Version 4.x (Windows and Linux version only)
Hardware	Standard PC, LAN

Notes:

- There may be import restrictions for some countries due to the 128-bit encryption.
- Depending on the server or operating system used, certain management functions may differ or not be available.

Standard functions of the iRMC S2

Browser Access

The iRMC S2 has its own web server, which can be accessed from the management station with a standard web browser. All sensor information, such as fan speeds, voltages, etc., and the complete configuration of the iRMC S2 are made available to administrators via the web user interface.

Security (SSL, SSH)

Access to the web server and the optional graphical console redirection, including the mouse and keyboard, can be protected by HTTPS/SSL (128-bit). Incorrect logins will be logged. To enable access to the iRMC S2 via the Remote Manager cryptographically secured communication can be established, which is protected by the SSH mechanisms. The Remote Manager is an alphanumeric user interface of the iRMC S2.

ServerView Operation Manager Integration

The ServerView agents detect the iRMC S2 and automatically assign it to the server in question. Text console redirection via the Remote Management web user interface and the web interface can be started directly from ServerView Operations Manager.

Power Management

Regardless of the system status, the following options for switching on/off the server from a remote workplace are provided:

- via the iRMC S2 web interface
- via the *Power Control* menu of the AVR window
- via the Remote Manager and the command line interface (CLI)
- per script

In this way, the server can be powered on, a power cycle can be initiated or the server can be gracefully shut down or shut down instantly (power button override), e.g. if the operating system no longer responds. In addition, an immediate or graceful reset (reboot) can be initiated.

Power Consumption Monitoring

To monitor system power consumption via the web interface several reports are provided. You can choose between reports for a single day, for a month or a year. Power Consumption Monitoring is not supported by all power supplies.

Power Consumption Control

Besides power monitoring also an operating system independent power consumption control is possible. The following operating states are selectable:

- Minimal Power Consumption: The CPU works always at lowest frequency and voltage
- Best Performance: Whole frequency and voltage bandwidth is available and can be selected by the operating system.
- Schedule: Allows switching between the above mode-depending on day of the week and time.

(These settings are CPU specific and are not available for all CPU types)

integrated Remote Management Controller - iRMC S2

Text Console Redirection

A Telnet session can be initiated on the iRMC S2 via the Remote Management web front-end. The Remote Manager is then called, by means of which text console redirection can be started, power management carried out, the error event log read or sensor information queried. Beside Telnet there is SOL (serial over LAN) and SSH (secure Shell) supported.

Headless System Operation

A keyboard, monitor and mouse are not required on the managed server. As a result, costs are reduced, cabling in the rack is simplified considerably and security is increased. Connection speed is optimized to the line bandwidth available.

Identification LED

The Identification LED of the managed system can be switched on via the iRMC S2 web interface to identify the system, for example in a fully configured rack.

LAN

In most PRIMERGY systems one LAN interface of the built-in NIC (network interface card) is reserved for the management LAN. In the remaining systems the LAN interface can be configured optionally for

- exclusive use by the management LAN
- shared operation with the system
- exclusive use by the system.



The management LAN interface of the system NIC is indicated by a wrench icon – it supports IPv4 and IPv6.

Command Line Interface (CLI)

The iRMC S2 not only supports the Remote Manager, but also the SMASH CLP (System Management Architecture for Server Hardware Command Line Protocol) standardized by the DMTF (Distributed Management Task Force).

Simple Configuration – interactive or scripted

The following tools are available to configure the iRMC S2:

- iRMC S2 web interface
- WinSCU
- Server management tool IPMIVIEW
- BIOS Setup

Scripted configuration via WinSCU or IPMIVIEW is also possible. In this way, the iRMC S2 can also be configured during initial setup of the server with ServerView Installation Manager. Scripting is also possible to configure a large number of servers simultaneously.

Local User Management

The iRMC S2 has its own user management system, in which up to 16 users with passwords can be created and granted different rights, depending on the group to which they belong.

User Management via Directory Service

The protocol used is LDAP (Lightweight Directory Access Protocol) or secure LDAP. The directory services Active Directory, openLDAP and eDirectory are supported. Therewith users can be managed centrally and have not to be managed via the iRMC S2.

DNS / DHCP

The iRMC S2 supports automatic network configuration. It has a default name and DHCP (Dynamic Host Configuration Protocol) is enabled so that iRMC S2 obtains its IP address from the DHCP server (in IPv4 only). The iRMC S2 name is registered with the Domain Name Service (DNS). Up to 5 DNS servers are supported. If no DNS/DHCP is available, static IP addresses are supported.

Online Firmware Update

The iRMC S2's firmware can be updated online since there are two independent images of the firmware on the motherboard. In case an error occurs during flashing, the redundant module can always be used as a backup.

Power Supply

Power to iRMC S2 is provided from the PRIMERGY system's internal standby power supply.

Alarm Management

The iRMC S2's alarm management system offers the following possibilities for alarm forwarding (alerting):

- Platform Event Traps (PETs) are sent via SNMP
- Direct notification by e-mail
- If the PRIMERGY systems provides a serial interface a modem can be connected for sending alerts (e.g. by SMS to a mobile phone).

In addition, the iRMC S2 supplies the ServerView agents with all relevant information.

Reading and Editing the System Error and Event Log (SEL)

The contents of the SEL can be viewed and deleted

- via the iRMC S2 web interface or
- via the Telnet-based interface (Remote Manager) of the iRMC S2.

The SEL can be stored locally via the web interface

Customer Self Service (CSS)

Not all components of a PRIMERGY server have to be replaced by Service. There are components you can replace on your own. These components are marked in the iRMC S2 web interface. This information is provided in ServerView Operations Manager as well. Additionally, a link is provided for easy purchasing of new CSS components.

Memory Prefailure Analysis

The iRMC S2 takes care of memory prefailure analysis.

integrated Remote Management Controller - iRMC S2

Optional components

The following components provide information on the system state directly at the server. Please note that these optional components are not available for all PRIMERGY servers and their usage also depends on the server's configuration.

ServerView Local Service Display (LSD)

The LSD is a LC-Display with 2x20 characters and a four-way navigation key. Among others error messages, Customer Self Service (CSS) information or system information can be retrieved via several information pages.



ServerView Local Service Panel (LSP)

The LSP is a display providing information on component states. In addition via LEDs information is provided which components you can replace on your own. The LSP is built into the front of the PRIMERGY system.



Enhanced functions of the iRMC S2 Advanced Pack

On top of standard functionality, the iRMC S2 additionally provides the functions Advanced Video Redirection (AVR) and Remote Storage. The enhanced functionality is enabled by means of a release key that can be ordered either with the system (S26361-F1790-E241) or subsequently (S26361-F1790-L241) and loaded via the web interface. The iRMC Advanced Pack is included for free in the basic configuration of PRIMERGY server blades like BX620 S6 and of the BX9xx series.

Advanced Video Redirection (AVR)

The iRMC S2 supports Advanced Video Redirection with the following benefits:

- Operation via a standard web browser; no additional software except Java Runtime Environment must be installed on the management station.
- System-independent graphics and text console redirection, including the keyboard and mouse
- Remote access to permit boot monitoring, BIOS administration and interaction with the operating system
- AVR offers up to two simultaneous "virtual connections" for working on a server from a different location. In addition, AVR minimizes the network load by means of hardware and video compression.

Remote Storage

Remote Storage makes available to the managed server a "virtual" drive which is located elsewhere in the network. The "virtual drives" provided by Remote Storage are as easy to use as local drives and offer the following options:

- Reading/writing of data
- Booting from Remote Storage
- Installation of drivers or small applications
- Remote BIOS update (BIOS update via USB)

Remote Storage permits simultaneous connection of up to two "virtual" drives and supports the following types of device:

- Floppy disk
- CD-ROM / DVD-ROM
- USB memory device (e.g. Memory Stick)
- ISO image

More information

Fujitsu platform solutions

In addition to Fujitsu PRIMERGY ServerView Suite, Fujitsu provides a range of platform solutions. They combine reliable Fujitsu products with the best in services, know-how and worldwide partnerships.

Dynamic Infrastructures

With the Fujitsu Dynamic Infrastructures approach, Fujitsu offers a full portfolio of IT products, solutions and services, ranging from clients to datacenter solutions, Managed Infrastructure and Infrastructure as-a-Service. How much you benefit from Fujitsu technologies and services depends on the level of cooperation you choose. This takes IT flexibility and efficiency to the next level.

Computing products

www.fujitsu.com/global/services/computing/

Software

www.fujitsu.com/software/

More information

Learn more about Fujitsu PRIMERGY ServerView Suite, please contact your Fujitsu sales representative, Fujitsu business partner, or visit our website.
www.ts.fujitsu.com/serveview

Fujitsu green policy innovation

Fujitsu Green Policy Innovation is our worldwide project for reducing burdens on the environment. Using our global know-how, we aim to resolve issues of environmental energy efficiency through IT. Please find further information at:
www.fujitsu.com/global/about/environment/



Copyright

All rights reserved, including intellectual property rights. Changes to technical data reserved. Delivery subject to availability. Any liability that the data and illustrations are complete, actual or correct is excluded. Designations may be trademarks and/or copyrights of the respective manufacturer, the use of which by third parties for their own purposes may infringe the rights of such owner. For further information see www.ts.fujitsu.com/terms_of_use.html
Copyright © Fujitsu Technology Solutions

Disclaimer

Technical data are subject to modification and delivery subject to availability. Any liability that the data and illustrations are complete, actual or correct is excluded. Designations may be trademarks and/or copyrights of the respective manufacturer, the use of which by third parties for their own purposes may infringe the rights of such owner.

Contact

FUJITSU LIMITED
Mies-van-der-Rohe-Straße 8
80807 München
Germany
website: www.ts.fujitsu.com
2011-07-14 CE-EN

All rights reserved, including intellectual property rights. Changes to technical data reserved. Delivery subject to availability. Any liability that the data and illustrations are complete, actual or correct is excluded. Designations may be trademarks and/or copyrights of the respective manufacturer, the use of which by third parties for their own purposes may infringe the rights of such owner. For further information see www.ts.fujitsu.com/terms_of_use.html
Copyright © Fujitsu Technology Solutions